

**Lippard CQBP**

**Pistol, Caliber .45, Automatic**

**Operator and Organizational  
Maintenance Manual  
Including Basic Issue Items List  
Repair Parts, Tools and Accessories**

## Table of Contents

1. Section I - Pistol, Automatic, Cal. .45, CQBP
2. Section II - Diagram and Pictures
3. Section III - Use of Tactical Sights
4. Section IV - Magazine
5. Section V - Disassembly and Assembly Instructions
6. Section VI - Cleaning
7. Section VII - Part Numbers

### WARNING

Care must be exercised to either have the pistol raised or pointed down range when loading.

Before firing, the firer must be sure that the bore of the pistol is free from any foreign matter. Firing a pistol with any obstruction in the bore will result in damage to the weapon and possible injury to personnel. **Do not adjust Trigger travel before reading page 19, line 6-3, e.**

Before starting an inspection, be sure to clear the weapon. Do not actuate the trigger until the weapon has been cleared. Remove magazine, inspect the chamber to insure that it is empty and check to see that no ammunition is in position to be introduced.

## Section I. Pistol Automatic, Cal .45 CQBP

- 1-1. General.** The semiautomatic pistol, caliber .45 acp, CQBP, is recoil operated, magazine fed, self loading hand weapon. It has a hand held point of aim range of 25 yards; an effective range up to 375 yards. It can be used to 550 yards with marksmanship instruction. It has the following characteristics:
- b. Weight with full magazine..... 3.3 pounds.
  - c. Magazine capacity.....7 rounds.
  - d. Muzzle velocity..... 859 feet per second.
  - e. Maximum Range .....1600 yards.
  - b. Maximum effective range .....375 yards.
  - c. Length of the barrel is ..... 5.03 inches.
  - d. Trigger pull .....5 pounds.
  - e. The principle parts that contribute to the accuracy of the CQBP are the *NCO barrel, Military Link, and NCO barrel Bushing*.
  - f. The CQBP Barrel has a *Barrel Collar*. It allows for barrel wear in the NCO Barrel Bushing. This extends barrel life to the limits of the rifling. Barrel material of the CQBP is 416 stainless or S7 high chromium tool steel. These materials insure accuracy beyond normal barrel limits and prevent corrosion and pitting.
  - g. *NCO Barrel Bushing* has internal grooves that lubricate the barrel and remove debris on each function cycle.
  - h. The *Barrel Linkage* to the Receiver has been tightened and enlarged for repeatability in firing and accurate lockup to the Slide.
  - i. The **Barrel torque** experienced in the former M1911A1 Barrel Link has been eliminated with the new *Military Link*. It forms a unified link the width of the barrel itself. Further no modification of the barrel is required and all the original fitting attributes of a M1911A1 barrel are unchanged. In additional, a Match Grade NCO Barrel comes on every CQBP pistol made.
  - j. The CQBP can accept 1911A1 barrels and barrel link without alteration. This combination provides greater barrel and slide life. Retrofitted, these components can bring most inactive guns back into shooting condition with a small frame alteration and link installation found in the CQBP.
  - k. The *Military Link* comes in 8 sizes to fit any wear adjustment to the limit of serviceability.
  - l. Many arms can be re-commissioned with CQBP modifications.
  - m. The *Military Link and Bushing* combination provide for absolute return to battery of the barrel when fired saving Slide and Barrel wear.
  - n. The additional attributes of the CQBP involve a Frame and Slide Modification. The CQBP can be used from -76 degrees to 2600 degrees Fahrenheit when using Nickel Anti Seize MIL-A-907E. This lubrication is deposited in fourteen cut recesses of the frame, slide, barrel bushing, slide stop and hammer components. As the firearm heats up the material bleeds into the action as required. Conversely in cold conditions it

remains a liquid to provide operational capability. Further, in extreme conditions such as HALO applications the gun can be used immediately without it seizing to the hand by subzero temperature.

- o. Magazine surfaces are further coated with Teflon an anti moisture application to prevent seizing in cold weather conditions.
- p. **The Receiver and Slide are made of S7 tool steel for 100% interchangeability of parts and components.**
- q. **The Ejection port** has been lowered and the back flared to deflect empty cartridges cases to the right and rear of the shooter.
- r. **Extended Slide Stop** allows for Slide release without shifting the hand position. It allows for use of either hand if needed. The tolerances have been improved between Receiver and Barrel Military Link. Surfaces have been recessed in three locations for Anti-Seize functionality in all weather conditions of friction.
- s. **Ambi Safety** allows for weak hand use of the pistol safety. A positive Safety on either side makes the Safety reliable for long use. The enlarged size facilitates manual operation under extreme conditions. A 2-56 threaded screw is that is required to service and clean the part.
- t. **The Sear ledge** has also been modified to channel debris that could invade the pistol from a cocked and locked condition away from the Sear ledge that could cause the pistol to fail.
- u. **The Hammer** has rebated side walls to prevent stoppage in a mud condition or fouling. On the inside frame contact surfaces are rebated providing a reservoir for anti-seize for functioning in extreme weather conditions but also to capture impurities invading the Hammer area contact space that could cause malfunctions.
- v. **The Grip Safety** cavity in the Receiver has been modified to eliminate the malfunctions found to occur from ice, mud, blood and other debris pressed into the Frame that prevents the Grip Safety from being applied.
- w. **The Firing Pin** has added serrations to clean the firing pin during firing preventing malfunctions.
- x. **The Front Sight is luminous. When combined with the two on the rear sight the three dots horizontally aligned provide a shooting plane for 25 yard point of aim firing accuracy.** It further **the front sight** has graduations of yardage in which the pistol can be aimed at 25, 200, 260 and 375 yards without sight adjustment if required.
- y. **The Rear Fixed Sight** is serrated to deflect light to a rear downward angle providing a clear sight picture without reflection to the eye under all conditions. The top rear surface has a luminous dot on either side of the aperture. When aligned with the front sight dot it presents a line of reference in which to accurately shoot point of aim to 25 yards. The upper edge surface of the Rear Sight provides a killing surface in the final use of a CQBP in a defense mode. An in Offensive mode an enemy can be dispatched if hit with the Rear Sight.
- z. **An Accessory Rail** integral to the frame of the CQBP provides to the use of addition accessories to be used.

**1-2. CQBP Accessories:**

- a. The CQBP can be *fully silenced* and take on **multi forms** to meet all combat situations. It has a **Rifle component** configuration. It can be upgraded to the Combat 1911A3 and 1911A4 systems in testing where **new ammunition** and components will be available if approved for military use.
- b. **The NCO Adjustable Rear Sight** is an accessory that looks almost exactly like Fixed Rear sight and shares its attributes. However it can be mechanically adjusted to move the sights for different ammunition.
- c. **A new NCO Sear** design allows for greater safety of the firearm under all conditions and trigger pulls. In conjunction with Sear Spring a choice of trigger pull weight can be selected from 2-12 pounds. It requires no fitting and the pull weight can be predetermined.
- d. **NCO NosePiece Accessory:** The CQBP may add a weighted nose piece to provide stability in a fully loaded condition of 7 rounds and stabilizes the CQBP in acquiring targets or providing suppressing fire at long distances. Further, the *NosePiece* can and does contain muzzle blast condensing said blast into an orange cone. The shooter retains night vision and suppresses visual complications with night vision optics.
- e. **NCO NosePiece Laser** can be installed in the lower disassembly hole on the NosePiece. That hole is threaded. An NCO Laser can be screwed into this receptacle and provide an aiming device in low light conditions and to laze targets up to 1 ½ miles to direct other munitions on targets.
- f. **NCO Ambi magazine release** allows for better ejection of empty magazine without shifting the hand to eject or remove with either hand. It allows magazine release in extreme cold.
- g. **A SolidRifle component** can be added to the lower unit or frame. A number of rifle calibers are available for special operations using the CQBP.
- h. **NCO .45 acp S7 barrels** can be ordered and retrofitted to CQBP. This barrel made for the Lippard Combat NCO 1911A3 uses advanced ammunition not currently available and is 16 times stronger than current barrels in use. The barrel will accept conventional .45 acp ammunition in service as well as the ultra high velocity ammunition in testing. The barrel is identified by the nomenclature located on the chamber hood.

**Section II. Diagram and Pictures**



**Fig. 1 Lippard CQBP**



**Fig. 2 Optional Nosepiece Component**

### **Section III. SIGHTS**

**3-1. SIGHTS.** The CQBP has multiple faceted Front Sights. One is for night illumination using a 3 dot horizontal plane for 25 yard shooting. In addition there are serrations that are used for deflection of light and a depository of color enhancement for different conditions. A “touch target system” is employed for offensive engagement close firing at distances from point blank to 50 yards and measured distances firing in sight graduations of 200, 260 and 375 yards.

a. The method of sight use is to always keep the target in the same location on the front sight blade regardless of distance. The CQBP will shoot flat to a distance of 125 yards by aligning the rear sight with the top of the front sight blade. The Front Sight

Blade is of such a size as to be readily picked up by the eye and an enemy “Touched” with the front Sight Blade is fired upon immediately and loosely aimed. Targets beyond 50 yards are aimed shots and the CQBP Front Sight allows for accurate shot placement to 125 yards.

b. A target estimated to be 200 yards the Rear Sight is dropped down to the first Front Sight notch. Here the trigger is pulled and a target reduced. This applies for the second notch on the Front Sight for 260 yds. You lower the Rear Sight again while holding the target at the same place on the top of the Front Sight blade and pull the trigger. A target deemed to be at 375 yards the Rear Sight is dropped down to the bottom of the Front Sight blade to its Sight base. That location is 375 yards for point of aim sighted pistols.

c. For Cover Fire up to 500 yards can be achieved by taking the target from the top of the Front Sight blade and dropping it down to the bottom and beside the front Sight blade where the Rear Sight is holding. Then slowly mode the Front and Rear Sights over to cover the target and the CQBP will shoot 500 yards without further sights adjustment for a point of aim sight pistol.





## **Fig. 3 Short Range Touch and Long Range Front Sight System.**

### **3-2. CQBP SIGHTING SYSTEM:**

a. The CQBP is 25 yard tactical weapon. Align the dot on the front sight in the middle of the two dots on either side of the rear sight. This alignment is now *point of aim* on the target at 25 yards. This same sight picture can be used up to 125 yards.

b. The CQBP can be called upon to shoot further. In a tactical situation the marksman will learn to *call target distances* in his mind. Up to 125 yards the CQBP can engage immediately and fire point of aim as with 25 yards. There are three more points on the CQBP front sight that allows a marksman to extend the range.

c. The CQBP front sight has a series of notches. The First notch is for 200 yards. The Second notch is for 260 yards. And the Third is the base of the front sight; 375 yards using standard 230 grain FMJ .45 acp military Hard Ball ammunition with sight set point of aim at 25 yards.

1. To sight the pistol at ranges indicated, the target is viewed the same as at 25 yards: *center mass*.
2. Drop the REAR sight down to align with the First range notch of 200 yards. Hold this position and squeeze the trigger until the pistol fires.
3. At 260 yards the same sight picture applies for the second notch.
4. At 375 yards the same picture applies when aiming at the BASE of the front sight of.

d. To shoot these distances requires a firm grip on the weapon with the right hand. The left hand is wrapped around the grip of the right hand, and the forefinger of the left hand, wrapped around the front of the weapon trigger guard. The trigger should rest under the PAD of the marksman's trigger finger.

e. When a marksman identifies a target at 200 yards; he "calls that distance to himself"; aligns his sights immediately to the proper notch on the front sight, and fires on that target is a matter of seconds with the CQBP battle sights. Practice shooting various distances on a man size silhouettes will quickly provide expertise in target distance identification and shooting skill.

f. In practice it is recommended that a marksman shoot into, and thru different types of cover such as steel vehicles, wood barriers, doors at various distances, to learn the penetration of the .45acp and full CQBP weapon capability. This will give confidence and experience at different ranges thus making the marksman fully qualified with the weapon and ready to engage targets to the limits of the CQBP effective range both at 25 yards, to the maximum range of its capability when called on to do so.

g. The CQBP front sight can be installed in conventional M1911A1's in upgrade without modification to the Slide.

**3-3. COVER FIRE.** *Cover fire* is covering the movement of another to a preferred position or, to a position of safety. There is another type of *Cover Fire* and that is to

protect, cover a front, or to augment your fire over another's position. Your position and location may NOT BE in the line of fire or even engaged. However another part of your unit may be engaged with a superior force where your combined fire can increase a unit's effectiveness. It may become necessary that all fire power of a supporting unit be brought to bear in Cover Fire. The CQBP gives marksman the ability to rain down *Cover Fire* from a safe distance to aid in such a tactical situation.

- a. For this type of fire the rear sight of the CQBP is lowered to the base of the front sight as with 375 yard shooting; however now the Target is no longer held center mass. The target instead is brought down *beside* the front sight to the *base* of the front sight. Then the front sight is moved horizontally over and covers the target. The weapon is slowly fired. That distance is 605 yards.

**3-4. COMBINED FIRE.** This goes hand in hand with *Cover Fire*. It uses the *Combined Fire* of all a units' assets to bring to bear on a given target. *Combined Fire* is a coordinated firing of pistol, combined with rifle, adding 10-15% to a unit's offensive firepower strength in a time of need for maximum effectiveness.

- a. The CQBP has the capability to provide cover fire up to 605 yards with existing sights. That means supporting fire on a target can be covered by a radius of 1,210 yards; a massive advantage to tactical operations. Marksman can engage from a distance which in turn demoralizes an enemy force into withdrawal or, reduces it by effective use of a CQBP.

**3-5. LIGHT CONDITIONS.** The CQBP has 3 illuminated dots; one on the front sight blade, and one either side of the rear sight. When aligned they provide a level sighting plane for point of aim shooting to 25 yards. However, the front sight blade also serrations which can also be used to illuminate the entire sight with the use of chalk, tooth paste, paint or any material available including spit and dirt.

- a. The use of chalk in white, orange, or any suitable color can be used intermittently with the natural Front Sight color or the dot configuration. Carry a couple of chalk sticks in the pocket.
- b. For indoor "house to house" low light conditions the Front Sight with illumination will provide sight identification. If chalk is used, when the indoor threat is reduced wipe the Front Sight with the thumb and select another color for a new light conditions or simply leave the natural color of the Front Sight until another light condition presents itself.

## Section IV. 7 Round Magazine

- 4-1. MAGAZINE.** The CQBP 7 round magazines are tempered steel and coated with Teflon to reduce friction and sticking to the hands during cold weather. A special 2 stage spring is used to insure continuous pressure on the rounds throughout the magazine cycle of 7 cartridges.



**Fig. 4 Seven Round Magazine with Cam Ne bumper Accessory**

## **Section V. DISSEMBLY INSTRUCTIONS**

**5-1. DISASSEMBLY OF THE WEAPON.** The Lippard CQBP is a variant of the Browning 1911 model. It has patented and improved parts and components.

1. Remove the magazine.
2. Point the weapon in a safe direction and open the slide; inspect to insure pistol is unloaded.
3. Close the Slide.
4. Place the weapons on manual safe with the hammer cocked.
5. Depress the Spring Plug.
6. Rotate the Bushing to the left until it clears the Spring Plug.
7. Slowly release the tension of the Recoil Spring holding in firmly on the Spring Plug.
8. Unlock the manual safety.
9. Open the Slide to the Slide Disassembly notch.
10. Remove the Slide Stop pin.
11. Remove the Slide.
12. Rotate the Barrel Bushing counter clock wise to the right and remove.
13. Remove the Recoil Spring, Spring Plug and Recoil Spring Guide.
14. Remove the barrel.

**To re-assemble, reverse the disassembly process.**



**Figure 5. Remove the Recoil Spring Plug**



**Fig. 6 Move Slide to the Slide Stop Disassembly Notch**



**Fig. 7 Remove the Slide**



**Fig. 8 Field Disassembly**

**5-2. LUBRICATION OF THE WEAPON.** A Lippard CQBP has fourteen reservoirs for Lubrication. Four on the Slide rails, two on the Frame rails, three inside the Barrel Bushing, 3 on the Slide Stop, and two on the Hammer. On these 14 areas you put recommended Lippard Nickel Anti-seize Mil-A-907E or issue MIL-PRF-14107D until these recesses are filled. As the pistol fires, it lubricates the Frame, Slide, Barrel, Military Link and Hammer to keep it from freezing, removing fouling, and as the gun heats up, bleeds lubrication to keep the pistol functioning. Only a small amount is needed on the pistol. It also can be shoot dry without harm to the pistol if lubrication is not available.



## Section VI. CARE AND CLEANING UNDER NORMAL CONDITIONS

**6-1. CLEANING OF THE WEAPON.** Cleaning is part of scheduled maintenance and should always begin with an inspection of the weapon system. Begin by field stripping the pistol, as described in para 5-1 on page 11. Use the tools and equipment listed in Table 6-2 to clean and lubricate the pistol. The pistol should be cleaned as soon as possible after firing, and each time it is exposed to field conditions.

**\*\*\*WARNING\*\*\***

**Make sure the pistol is safe before cleaning. Ensure that the pistol is not loaded.**

To clean a Lippard CQBP that has seized, does not function, or has become fouled; apply AntiSeize MIL-A-907E to the frame rails and hand cycle the pistol 10 times until free and cycling smoothly. The pistol now has suspended the fouling. It can be wiped clean or cleaned normally with MIL-PRF-63460D Cleaner.

**NOTE:** In combat conditions where no cleaning equipment is available, a seized or non-functioning weapon Slide and Frame can be cleaned with common sand; either scrubbed or cycled with the same and then brushed, wiped or rinsed with water or any liquid available. It is not necessary to lubricate to use the weapon and unlikely that any condition can reduce its combat capability.

The standard cleaning kit for the CQBP is the NSN 1005-01-455-0575.

a. Rust.

1. Rust on the weapon can be caused by acid chemical reaction with the low carbon metal properties but is only superficial. It is not harmful to the weapon as S7 is extremely resistant to salt or corrosive chemicals. A bare surface can be renewed with use of “Scotch Brite” type cleaning pad.

b. Bore and Chamber.

1. Cleaning is normal for stainless 416 materials and S7 NCO barrels. Assemble cleaning rod with bore brush. Wet bore brush with CLP or riffle bore cleaner (RBC). Caution: Never reverse direction of the bore brush inside the bore. This damages the bore brush and could damage the bore as well.
2. Insert the cleaning rod into the bore and push carefully until the bore brush protrudes completely from the chamber. Pull bore brush back through clearing the chamber. Repeat this procedure several times keeping the bore brush wet.
3. Assemble cleaning rod with the swab holder. Insert a clean swab on the cleaning rod and run the swab through the bore and out of

the chamber. Change swabs and continue until a swab comes out clean.

c. Slide Assembly.

1. Scrub the face of the slide with the small cleaning brush (toothbrush). With a swab or rag dampen with CLP, wipe all outer surfaces. Be sure to remove all primer residue and to clean in and around the exterior of the recoil spring plug.
2. Use CLP to clean the recoil spring guide and helical spring. Keep the *shok-buff* clean if present, clean and dry. Clean both the interior and exterior of the recoil spring plug.
3. Use CLP to clean both the interior and exterior of the barrel bushing.

d. Receiver.

1. The hammer, ambidextrous thumb safety, magazine catch, trigger and trigger guard all be scrubbed down using a cleaning brush and CLP. Use cotton tip applications to clean hard to reach areas.

e. Slide Stop. Clean the slide stop pin with rag dampened with CLP.

f. Barrel Bushing. Clean the barrel bushing internal grooves with rag dampened with CLP.

g. Magazine Assembly. Clean the magazine with rag dampened with CLP. In combat conditions the magazine can be washed empty or loaded with water. A drain hole is provided to extricate sand and debris in or out of the pistol.

**6-2. LUBRICATION THE WEAPON.** Field strip the weapon (para 5-1 on page 11) and lubricate in accordance with TM 9150-15/1. Caution: Use only authorized lubrication. Do not mix lubricants. In addition there are fourteen lubrication reservoirs that accept MIL-A-907E. They are: Barrel bushing grooves, slide stop, hammer, receiver and slide grooves. Only a small amount of MIL-A-907E is needed on the pistol to keep it functional in all conditions.

- a. Use CLP, an approved weapon lubricant, e.g. LSA, LSA-T, or LAW to moderately lubricate the following areas:
  1. Guide rails of the receiver assembly
  2. Grooves internally on the receiver rails
  3. Grooves internally of the barrel bushing
  4. Guide rails of the receiver assembly
  5. Grooves internally on the slide rails
  6. Grooves internally on the hammer

- b. Lightly lubricate all other areas, including the bore and the magazine well. If the pistol has been exposed to salt water, dry it thoroughly, clean, and lubricate as soon as possible. Do not use spray on the magazine but spray on a rag and then wipe the magazine.

**Caution**

**Excessive oil could cause loss of control during firing.**

- c. Prior to loading the pistol, attention should be directed to wiping all visible oil from the bore and exterior areas. Do not spray the pistol with oil. Ally oil to a rag and then wipe the pistol. Keep the pistol dry of oil.

**6-3. SAFETY CHECK TESTS.** Whenever the CQBP .45 caliber Pistol is reassembled, perform the below listed safety checks. If the safety checks perform as indicated, the pistol is operationally ready. If the checks do not perform as indicated, report the problem to the unit Armorer.

**Warning**

**Make certain the pistol is cleared.**

- a. **Manual Safety.** With the hammer cocked and the weapon ON manual safety and the hand grasping the grip safety, pull the trigger. If the hammer does not fall the manual safety is working properly.
- b. **Grip Safety.** With the hammer cocked and the weapon OFF manual safety and the hand NOT grasping the grip safety, pull the trigger. If the hammer does not fall the grip safety is working properly.
- c. **Half-cock Notch.** Draw back the hammer until the sear engages the half-cock notch and squeeze the trigger. If the hammer falls the sear or the hammer must be replaced.
- d. **Disconnect.** Cock the hammer. Shove the slide one-quarter inch to the rear; hold slide in that position and squeeze the trigger. Let the slide go forward maintaining pressure on the trigger. If the hammer falls, the disconnect is worn and must be replaced.
- e. **Trigger:** The trigger is adjustable for length of travel. **Too much adjustment will cause the Sear to disengage from the hammer.** The hammer in turn can follow the Slide when closed during loading. But sure to have some free float in the trigger movement before a tension stop of the trigger is felt. To widen the gap and increase trigger pull turn the set screw counter clockwise ¼ turn or more.

## Section 7

### Part Numbers and Tools

No.	Part
	1 Barrel NCO .5808-.581
112	Bushing NCO .582
113	Bushing NCO .581
114	Bushing NCO .580
115	Bushing NCO .579
116	Bushing NCO .578
117	Bushing NCO .577
	225 Nose Piece NCO .582
	226 Nose Piece NCO .581
	227 Nose Piece NCO .580
	228 Nose Piece NCO .579
	229 Nose Piece NCO .578
	230 Nose Piece NCO Cmdr .582
	231 Nose Piece NCO Cmdr .581
	232 Nose Piece NCO Cmdr .580
	233 Nose Piece NCO Cmdr .579
3A1	Military Link undersize 1
3A2	Military Link size std 2
3A3	Military Link size 3
3A4	Military Link size 4
	4 Barrel Link Pin
	5 Disconnecter
	6 Ejector
	7 Ejector pin
	8 Extractor
	9 Firing Pin .45
	11 Firing Pin Spring
	12 Firing Pin Stop
	13 Grips Pachmayr CQBP
	16 Hammer pin
	17 Hammer Strut
	18 Hammer Strut pin
	19 Magazine
19A	Cam Ne Bumper
19B	Cam Ne Screws
	20 Mag Release Ambi
	21 Magazine Spring
	26 Main spring cap
	27 Main spring cap pin

- 28 Mainspring Housing
- 288 Mainspring Housing Loop
- 289 Mains Housing Loop Pin
- 29 Mainspring Housing pin
- 30 Main spring cap retainer
- 31 Plunger spring
- 35 Recoil Spring 16.5
- 36 Recoil Spring Guide
- 37 Recoil Plunger plug
- 41 Sear Pin
- 42 Sear Spring
- 43 Front Site CQBP
- 44 Rear Site CQBP
- 441 Rear Site NCO
- 442 Rear Site NCO Adjustable
- 471 Slide Stop NCO
- 45 Slide CQBP
- 47 Slide Stop NCO
- 49 Grip Screws 4 set
- 50 Grip bushing 4 set
- 51 Trigger
- 53 Grip Safety NCO
- 54 Hammer NCO Commander
- 544 Hammer Standard
- 55 Mag Follower
- 56 Mag spring
- 57 Mainspring
- 59 Frame CQBP
- 60 Safety Ambi NCO Left
- 61 Safety Ambi NCO Right
- 62 Safety Ambi Post
- 63 Safety Ambi Pin
- 64 Safety Ambi Screw 2-56
- 65 Sear Chip NCO
- 66 Tool Kit Small Arms TK-2111**